

# noVus<sup>®</sup>

## Elevator controller

### NVE-ELV200



The lift controller realizes centralized management by connecting indoor monitor, outdoor panel and Wiegand card reader. With easy operation and setting, this device meets users' diversified needs. The module has two operating modes. The module relays can be connected directly to the elevator buttons or to the PLC inputs. Lift controller can be set to master and slave types. In one lift controller unit, the Master Controller communicates with other slave lift controller by RS485.

|                    |   |
|--------------------|---|
| Device type        | Elevator controller   |
| Power supply input | 12 V DC   |
| PoE                | 18 V DC (NVE-SW200-7P), 48 V DC (802.3af)                   |
| Relays             | 16 x NO / NC  |
| Port LAN           | 1 x 10M / 100M Ethernet                                     |
| Card reader format | Interface Wiegand 26  |
| Support            | 1 Elevator, 1 controller up to 16 floors maximum 128 floors |